



Installation Information

Item #P0085

Lavatory Pop-Up Drain Assembly

1. Separate the drain flange from the pop assembly
2. Apply silicone caulking to underside of drain flange.
3. Insert the pop-up assembly from underside through sink. Slowly screw into the drain flange until it stops. Tighten the brass nut on pop-up assembly from below compressing rubber gasket onto the sink.
4. Insert ball rod into the drain body so that the short end of the ball rod fits into the base of the stopper. Snug the ball rod nut to seal, allowing it to move up & down freely.
5. Insert the pop-up rod through the spout and rod strap. Use thumbscrew on rod strap to tighten to the pop-up rod.
6. Install the hole strap onto the ball rod using pinch clamp to secure.

